



How the ORIGOSafe™ works

- ✦ When you receive your ORIGOSafe™, the administrator will authorize all phones, and configure all safety settings through use of the ORIGO™ keypad
- ✦ The driver will place his or her phone in the ORIGOSafe™ docking station and start the vehicle in the normal manner.
- ✦ The driver can then engage handsfree technology, and make verbal commands as usual.
- ✦ If the phone is removed from the docking station at any time during a trip, ORIGOSafe™ will sound an alarm until the phone is replaced. The next time the driver tries to start the vehicle, he or she must contact the administrator in order for the phone to be reauthorized. These settings are completely configurable by the administrator.
- ✦ If the phone is lost or stolen, a One Time Use code can be obtained from the administrator to start the vehicle.
- ✦ If the vehicle is taken to be serviced, or left with a valet, simply provide the guest driver with the PIN you have created, and he or she will be able to operate the vehicle normally.
- ✦ All of the details and configurations of the ORIGOSafe™ unit are easily controlled by the administrator/vehicle owner. You can set all time limits, add and change the number of users & phones, customize and administer codes, and tailor all other information to your needs and the needs of your driver(s).
- ✦ The ORIGOSafe™ charges the phone while it rests in the docking station.

The ORIGOSafe™ Commercial version is accompanied by the ORIGOCommand™ fleet management package. This iPad application allows fleet/risk managers to monitor driver behavior, easily add and remove authorized users, and much more.

